



- Notes:
- 1) Use this Diagram to wire EVO Speed control to Regal Beloit ECM motors
 - 2) Cap all (not used) leads with wire nuts
 - 3) Leads can be cut to length as needed
 - 4) Read out on control is percent of motor full RPM (See Chart)

Read out %	Motor RPM
100	1800
90	1620
80	1440
70	1260
60	1080
50	900
40	720
30	540
20	360

